

BEKO, FLAVEL & LEISURE GAS COOKERS

It has recently come to our attention that particular Beko, Flavel and Leisure cookers with a separate oven and grill can, if they are not operated in accordance with the user instructions, pose **a serious risk to your health**.

These appliances are designed for cooking purposes only and **must NOT** be used as a space heater, or for any other purpose.

CHECK THE LIST BELOW TO SEE IF YOU OWN ONE OF THE AFFECTED COOKERS

Brand	Product Model Number
Beko	DCG8511WLPG *
Beko	DCG8511PLW *
Beko	DG581LWP *
Flavel	DCGAP5LS
Flavel	AP5LDWP
Flavel	AP5LDW
Flavel	AP5LDSP
Flavel Milano	ML5NDS
Leisure	CM10NRK
Leisure	CM10NRC
Leisure	AL6NDW
Leisure	CM101NRCP
Leisure	CM101NRKP

* Instruction manuals for these products can be found on the Beko web site: www.beko.co.uk

WHAT YOU NEED TO DO IF YOU OWN ONE OF THESE COOKERS
1. FOLLOW THE PRODUCT INSTRUCTION MANUAL AND DO NOT OPERATE THE GRILL WITH THE GRILL DOOR CLOSED.

When the grill burner is on, the grill door must **always** be in the open position. If the grill is operated with the grill door closed, the air supply to the grill burner is restricted which can cause extremely dangerous levels of carbon monoxide to be produced which can pose a very serious risk to health.

2. ARRANGE FOR A FREE SAFETY INSPECTION AND MODIFICATION

If you own or use any of the models shown above, please call us on:

Free phone UK 0800 294 3129 Free phone Ireland 1800 25 29 25

We will then arrange to carry out a **free modification** to your product to remove any risk.

When calling please have your full model number and serial number to hand - these can be found on the rating plate at the bottom front edge of the appliance (see details below).



Beko plc, Beko House, Caxton Way, Watford WD18 8UF
 Beko plc, Unit 16, The Hub Logistics Park, Bracetown, Clonee, Co Meath, Ireland

www.beko.co.uk www.leisurecp.co.uk